

Delcote® GS

Gutter coating 10 year guarantee

Preparation

Clean out the gutter thoroughly, removing all standing water, foliage, dirt, and debris. All loose and flaking and all previously applied non compatible coatings, should be removed from the entire area to be coated.

On galvanised steel or cast iron gutters, the surface should be prepared to a minimum Swedish Standard ST2 - back to base substrate, clean and dry, by using hand and power tools.

No oil, grease and dirt, should be visible to the naked eye. All poorly adhered mill scale, rust, swarf, coatings and foreign matter, must be removed.

Passivate (T-wash) unweathered or shiny galvanised substrates with suitable mordant solution.

On asbestos cement and concrete gutters, remove all standing water, old treatments, dirt, grease, and surface contamination. Refer to HSE guideline sheets on cleaning weathered asbestos cement substrates.

Additional Preparation For Gutter Joints

Loose and flaking coatings, and existing seals should be removed. Gutter bolt threads should be cropped close to the nut where applicable.

The joint area including bolts/fixings should be prepared to a minimum of Swedish Standard ST3 - back to bare metal using a powered mechanical aid, ie angle grinder with a grinding disk or heavy duty knotted wire wheel, ensure the surface is fully keyed and not polished.

The gutter substrate and joints must be thoroughly clean and dry before the application of Sharmans products. A mechanically driven leaf blower may be used to achieve this.

Thoroughly clean the surface using Isopropyl Alcohol.

Note: Do not at any time clean the surface with soap detergent. This action would leave a residual film and may adversely affect adhesion.

Note: This is an outline specification for the general application of this system. For a bespoke specification to deal with site complexities, please contact us.

Product Application

Sharmans Barrier Primer - (Where Applicable)

Bitumen and other volatile materials must be removed. Any remaining residue must be primed with Sharmans Barrier Primer as follows:

Thoroughly mix parts A and B together (do not part mix).

Apply by brush at a wet film thickness of 157 microns (6m²/litre) and leave to dry to a tack free state.

Seamsil® Sealant

Seamsil® Sealant is gun-applied 10-12mm diameter to encapsulate the joints of the gutter and around and over the bolts/fixings forming a complete bridged seal.

Seamsil® Base Coat

Whilst the Seamsil® Sealant is still wet, apply Seamsil® Base Coat by brush at a minimum wet film thickness of 220 microns. Allow to cure to a tack free state.

Seamsil® Base Coat should be applied at least 25mm either side of the gutter joint, ensuring complete coverage of the joint and bolts/fixings.

For neat aesthetics, the coating should be applied in a straight line. To aid this, a pencil line or a straight edge can be used.

The finished Seamsil® treatment must form a fillet across the joint that visually obscures the abutting plates.



sharmans

gutter & roof refurbishment systems

Delcote® GS

Gutter coating
10 year guarantee

Gutter Coating System

Delcote® GS Base Coat

Ensure Seamsil® joint and bolt treatment is tack free.

Utilising roller or brush, apply a first coat of Delcote® GS (Goosewing Grey) to prepared, clean & dry, structurally sound surfaces, at a wet film thickness of 250 microns. Allow to cure to a tack free state.

Delcote® GS Top Coat

Once the base coat is tack free apply a second coat of Delcote® GS in a contrasting colour (Slate Grey) at a wet film thickness of 250 microns. Allow to fully cure.

The Completed System Dry Film Thickness:

Gutter Area: minimum 300 microns

Gutter Joints: minimum 475 microns

Application Notes

At all times ensure that the surface to be treated is clean and dry.

All swarf arising out of the metal preparation must be immediately brushed off the surface to avoid contamination of coated areas and existing surface coatings.

Failure to remove the swarf could result in subsequent rust staining by the debris arising out of the metal preparation operation.

Disclaimer: The information, and, in particular, the recommendations relating to the application and end-use of products, are given in good faith based on current knowledge and experience of the products when properly stored, handled and applied under normal conditions. In practice, the differences in materials, substrates and actual site conditions are such that no warranty in respect of merchantability or of fitness for a particular purpose, nor any liability arising out of any legal relationship whatsoever, can be inferred either from this information, unless from any written recommendations, or from any other advice offered by HD Sharman. The proprietary rights of third parties must be observed. All orders are accepted subject to our current terms of sale and delivery. Users must always refer to the most recent issue of the Product Data Sheet for the product concerned, copies of which will be supplied on request.

Where there are slight perforations present, the substrate can be covered by riveting a metal plate into place and sealing the edges using Seamsil® Sealant and base coat.

Seamsil® base coat may be thinned by up to 10% to ease application. Only use Seamsil® thinners T514.

Note: White Spirit is strictly not to be introduced into the application system. This will adversely affect adhesion and invalidate the material guarantee.

Care must be taken not to disturb the uncured Seamsil® seal to the sheet joints once applied.

Delcote® GS is supplied ready to use and does not require thinning. The introduction of additional thinning will invalidate the material guarantee.

Allow each coat to cure until a tack free state is achieved before applying further coats. Curing times will vary with weather conditions. Refer to product data sheets.

Application air temperature must be above 3°C and rising.

Application surface temperature must be 2°C above dew point.

The installing contractor must be fully trained in the use of Sharman's coatings.

It is the contractors' responsibility to inspect each section of the application to ensure the correct measures and steps outlined in this specification document are applied.

Coverage rates are for guidance purposes only.

HD Sharman Ltd.
High Peak Works
Chapel-en-le-Frith
High Peak, Derbyshire
SK23 0HW

T. 01298 812371
F. 01298 812237
E. info@hdsharman.co.uk
W. hdsharman.co.uk



sharmans
gutter & roof refurbishment systems