


# Daikin Simplified Room Thermostat Controller Guide



## 1. Space heating control

- Opens the room temperature home page
- Shows current room temperature

## 2. Domestic hot water control

- Opens domestic hot water temperature home page
- Shows current hot water temperature

## 3. Domestic hot water tank booster mode

- Activates the domestic hot water booster mode

## 4. On/off


- Turns on or off one of the controls, depending on which home screen is shown on the display

## 5. Navigation buttons


- Navigates through the menu structure, selects and changes settings

# How to use your simplified room thermostat

## Adjust the desired room temperature

Press  to access the room temperature home page. This will show you the current room temperature. Use the  or  button to change the desired room temperature.

## Checking hot water temperature

Press  to access the hot water home page. This will show you the current temperature of the hot water in the tank. If you do not have a tank, this will show you the set temperature of your instant hot water.

## Additional hot water other than pre-set times (boost function)

If you run out of hot water you can go into booster mode.

Press  to start boost function; this will increase the stored temperature of the tank till it reaches the desired temperature.

**Note:** This function is only available on systems with domestic hot water tanks.

## Turning space heating or hot water off

If you require to turn off your space heating or hot water, you can do so by pressing either  or  to take you to the relevant home page. Then press  and the green light  will turn off.

To switch the space heating or hot water back on again, press either  or  and then press  and the green light will come on.

[daikin.co.uk](http://daikin.co.uk)

Dedicated homeowner support line: 01932 879271

Heating installer line: 01932 879070

The present leaflet is drawn up by way of information only and does not constitute an offer binding upon Daikin UK. Daikin UK has compiled the content of this leaflet to the best of its knowledge. No express or implied warranty is given for the completeness, accuracy, reliability or fitness for particular purpose of its content and the products and services presented therein. Specifications are subject to change without prior notice. Daikin UK explicitly rejects any liability for any direct or indirect damage, in the broadest sense, arising from or related to the use and/or interpretation of this leaflet. All content is copyrighted by Daikin UK.